

TECH300 LOOK UP CHART

ver 3.13
May 2007

MAKE	MODEL	YEAR	SENSOR	1	2	3	4
Acura	MDX	2004-06	TRW				●
	MDX	2007	Pacific ³		●	●	●
	RDX	2006	Pacific ³		●	●	●
	RL	2005-06	TRW				●
	TL	2006	TRW				●
	TSX	2007	Pacific ³		●	●	●
Audi	A4 / A6 / S4 & Quattro	2005-07	Beru ⁸	●		●	●
	A8 & Quattro	2001-02	Beru ¹			●	●
	A8 & Quattro	2003	Beru ⁹			●	●
	A8 & Quattro	2004-06	Beru ⁸	●		●	●
	Allroad	2005-07	Beru ¹			●	●
	Q7	2007	Beru ⁸	●		●	●
	RS6	2003	Beru ¹			●	●
	S8	2007	Beru ¹			●	●
BMW	3 Series	2001-07	Beru ¹			●	●
	5 Series	2001-07	Beru ¹			●	●
	6 Series	2005-07	Beru ¹			●	●
	7 Series	2004-07	Beru ¹			●	●
	Alpina	2004	Beru ¹			●	●
	M3	2001-07	Beru ¹			●	●
	M5	2006-07	Beru ¹			●	●
	X3	2006-07	Beru ¹			●	●
	X5	2007	Beru ⁸	●		●	●
	Z4	2003-07	Beru ¹			●	●
	Z8	2002-03	Beru ¹			●	●
Buick	Rainier	2006-07	Schrader	●			
	LaCrosse	2007	Schrader	●			
	LeSabre	2007	Schrader	●			
	Lucerne	2007	Schrader	●			
Cadillac	CTS	2004-07	Schrader	●			
	DeVille	2001-05	Schrader ²				●
	DeVille DTS	2006-07	Schrader	●			
	Escalade	2004-07	Schrader	●			
	Escalade ESV / EXT	2004-07	Schrader	●			
	Seville SLS	2001-04	Schrader ²				●
	Seville STS	2001-03	Schrader ²				●

TECH300 LOOK UP CHART

ver 3.13
May 2007

	STS	2005-07	Schrader	●				
	SRX	2004-07	Schrader	●				
	XLR	2004-07	Schrader	●				
Chevrolet	Avalanche 1500/2500	2004-07	Schrader	●				
	Colorado	2007	Schrader	●				
	Corvette	1997-04	Schrader ²				●	
	Corvette	2005-07	Schrader	●				
	Equinox	2007	Schrader	●				
	Impala	2006-07	Schrader	●				
	Monte Carlo	2006-07	Schrader	●				
	Silverado	2004-07	Schrader	●				
	SSR	2006-07	Schrader	●				
	Suburban 1500/2500	2004-07	Schrader	●				
	Tahoe	2004-07	Schrader	●				
	Trailblazer	2006-07	Schrader	●				
	Chrysler	300	2005-07	Siemens			●	
		300M	2002-04	Schrader	●			
Aspen		2007	Siemens			●		
Concorde		2002-04	Schrader	●				
Crossfire		2004-07	Siemens	●			●	
Pacifica		2005-07	Siemens			●		
Prowler		2002	Schrader	●				
Sebring		2007	Siemens			●		
Town & Country		2002-03	Schrader	●				
Town & Country		2004-07	Siemens			●		
Dodge	Caliber	2007	Siemens			●		
	Caravan	2004-07	Siemens			●		
	Caravan	2002-03	Schrader	●				
	Charger	2005-07	Siemens			●		
	Durango	2006-07	Siemens			●		
	Grand Caravan	2005-07	Siemens			●		
	Magnum	2004-07	Siemens			●		
	Nitro	2007	Siemens			●		
	Stratus	2007	Siemens			●		
	Viper	2003-06	Schrader	●				
	Ford	Edge	2007	Ford Corp.			●	
Escape		2006-07	Ford Corp.			●		
Expedition		2003-06	Schrader	●				
Expedition		2007	Ford Corp.			●		
Explorer		2006-07	Ford Corp.			●		

TECH300 LOOK UP CHART

ver 3.13
May 2007

	Explorer	2002-05	Schrader	●			
	F-150	2007	Ford Corp.		●		
	Freestar	2006-07	Ford Corp.		●		
	Freestar	2004-05	Schrader	●			
	Mustang	2007	Ford Corp.		●		
	Ranger	2005	Schrader	●			
GMC	Canyon	2007	Schrader	●			
	Envoy	2006-07	Schrader	●			
	Sierra	2006-07	Schrader	●			
	Yukon	2004-07	Schrader	●			
	Yukon Denali	2004-07	Schrader	●			
	Yukon XL	2004-07	Schrader	●			
Honda	CR-V	2007	Pacific ³		●	●	●
	Element	2007	TRW				●
	Odyssey	2005-07	TRW				●
	Pilot	2005-07	TRW				●
	Ridgeline	2006-07	TRW				●
	<small>NEW SENSORS ONLY</small> Accelerometer Enable	2006-07	TRW ⁷	●	●	●	●
Hummer	H3	2006-07	Schrader	●			
Hyundai	Elantra	2007	Beru/Lear			●	●
	Entourage	2007	Beru/Lear			●	●
	Grandeur	2007	Beru/Lear			●	●
	Santa Fe (CM)	2007	Beru/Lear			●	●
	Santa Fe (NF)	2007	TRW				●
	Sonata	2007	TRW				●
	Terracan	2007	Beru/Lear			●	●
	Tucson LTD	2006-07	TRW				●
Infiniti	FX35	2003-06	Schrader	●			
	FX45	2003-06	Schrader	●			
	G35	2004-07	Schrader	●			
	M35	2006	Schrader	●			
	M45	2003-06	Schrader	●			
	Q45	2003-06	Schrader	●			
	QX4	2003	Schrader	●			
	QX56	2004-06	Schrader	●			
Isuzu	Ascender	2006-07	Schrader	●			
	I series pick up	2007	Schrader	●			
Jaguar	XJ8	2006-07	Siemens			●	
	XJR	2006-07	Siemens			●	
	XK	2007	Siemens			●	

TECH300 LOOK UP CHART

ver 3.13
May 2007

	XKR	2007	Siemens			●	
Jeep	Commander	2006-07	Siemens			●	
	Compass	2007	Siemens			●	
	Grand Cherokee	2002-04	Schrader	●			
	Grand Cherokee	2005-07	Siemens			●	
	Liberty	2002-04	Schrader	●			
	Liberty	2005-07	Siemens			●	
Kia	Amanti	2007	TRW				●
	Carens	2007	Beru/Lear			●	●
	Optima	2006-07	Beru/Lear			●	●
	Sedona	2006-07	Beru/Lear			●	●
	Sorento	2007	TRW				●
	Spectra	2007	TRW				●
	Sportage	2006-07	TRW				●
	Rio	2007	TRW				●
Land Rover	LR3	2005-07	Siemens			●	●
	Range Rover	2002-07	Siemens			●	●
	Ranger Rover Sport	2005-07	Siemens			●	●
Lexus	ES350	2007	Pacific ³		●	●	●
	GS300	2006-07	Pacific ⁴		●	●	●
	GS430	2006-07	Pacific ⁴		●	●	●
	GX470	2005-07	Pacific ⁴		●	●	●
	IS250	2006-07	Pacific ⁴		●	●	●
	IS350	2006-07	Pacific ⁴		●	●	●
	LS460 & 600	2007	Pacific ³		●	●	●
	LX470	2006-07	Pacific ⁴		●	●	●
	RX350 & 400h	2007	Pacific ³		●	●	●
	SC430	2005-07	Pacific ⁴		●	●	●
Lincoln	Aviator	2003-05	Schrader	●			
	Mark LT	2007	Ford Corp.		●		
	Navigator	2007	Ford Corp.		●		
	Navigator	2003-06	Schrader	●			
Mazda	3	2004-06	Siemens ⁵			●	
	5	2006-07	Siemens			●	
	6	2005-07	Siemens			●	
	B series pick up	2007	Siemens			●	
	CX7	2006-07	Siemens			●	
	Miata	2004-07	Siemens			●	

TECH300 LOOK UP CHART

ver 3.13
May 2007

	RX8	2004-06	Siemens ⁵			●	
	Tribute	2006-07	Ford Corp.		●		
Mercedes-Benz	CL Class	2000-06	Beru ¹			●	●
	CLK	2006-07	Beru ¹			●	●
	CLS	2006-07	Siemens			●	
	E Class	2001-05	Beru ¹			●	●
	E Class	2006-07	Siemens			●	
	GL Class	2007	Siemens			●	
	M Class	2006	Siemens	●			●
	R Class	2007	Siemens	●			●
	S Class	2006-07	Siemens			●	
	S Class	2000-05	Beru ¹			●	●
	SL Class	2006-07	Siemens			●	
	SL Class	2001-05	Beru ¹			●	●
	SLR McLaren	2005-06	Beru ⁸	●		●	●
	Mercury	Mariner	2006-07	Ford Corp.		●	
Monterey		2006-07	Ford Corp.		●		
Monterey		2004-05	Schrader	●			
Mountaineer		2006-07	Ford Corp.		●		
Mountaineer		2002-05	Schrader	●			
Mini	All	2007	Beru			●	●
Mitsubishi	Endeavor	2004-06	Schrader	●			
	Galant	2004-07	Schrader	●			
	Montero	2003-06	Schrader	●			
	Outlander	2006-07	Schrader	●			
Nissan	350Z	2004-07	Schrader	●			
	Altima	2005-07	Schrader	●			
	Armada	2004-07	Schrader	●			
	Cedric	2005-07	Schrader	●			
	Cema	2005-07	Schrader	●			
	Frontier	2004-07	Schrader	●			
	Fuga	2005-07	Schrader	●			
	FX 35	2005-07	Schrader	●			
	Gloria	2005-07	Schrader	●			
	Maxima	2006-07	Schrader	●			
	Murano	2004-07	Schrader	●			
	Pathfinder	2004-07	Schrader	●			
	Quest	2004-07	Schrader	●			
	Sentra	2007	Schrader	●			

TECH300 LOOK UP CHART

ver 3.13
May 2007

	Skyline	2005-07	Schrader	●			
	Titan	2004-07	Schrader	●			
	Versa	2007	Schrader	●			
	Xterra	2003-07	Schrader	●			
Pontiac	Grand Prix	2007	Schrader	●			
	Torrent	2007	Schrader	●			
Porsche	911	2006-07	Beru ¹			●	●
	Boxter	2006-07	Beru ¹			●	●
	Carerra GT	2004-06	Beru ⁸	●		●	●
	Cayenne	2005-07	Beru ¹			●	●
	Cayman	2007	Beru ⁸	●		●	●
Saab	9-7x	2007	Schrader	●			
	9-3	2004-07	Schrader	●			
Saturn	Aura	2007	Schrader	●			
	Outlook	2007	Schrader	●			
Scion	tC	2007	Pacific ³		●	●	●
Subaru	B9 Tribeca	2006-07	Schrader	●			
	Legacy	2005-07	Schrader	●			
	Outback	2005-07	Schrader	●			
Suzuki	Forenza	2007	Schrader	●			
	Grand Vitara XL-7	2005-07	Schrader	●			
	SX4	2007	Schrader	●			
	Verona	2005-07	Schrader	●			
	XL-7	2005-07	Schrader	●			
Toyota	4Runner	2004-07	Pacific ⁴		●	●	●
	Avalon	2007	Pacific ³		●	●	●
	Cammary/Solara	2007	Pacific ³		●	●	●
	Highlander	2007	Pacific ³		●	●	●
	Land Cruiser	2006-07	Pacific ⁴		●	●	●
	Prius	2006-07	Pacific ⁴		●	●	●
	RAV4	2006-07	Pacific ⁴		●	●	●
	Sequoia	2005-07	Pacific ⁴		●	●	●
	Tacoma	2006-07	Pacific ⁴		●	●	●
	Tundra	2005-07	Pacific ⁴		●	●	●
Volkswagen	EOS	2007	Siemens ⁶			●	
	Golf	2006-07	Siemens ⁶			●	
	Jetta	2005-07	Siemens ⁶			●	

TECH300 LOOK UP CHART

ver 3.13
May 2007

	Passat	2006-07	Siemens ⁶			●	
	Phaeton	2005-07	Beru ¹			●	●
	Touareg	2005-07	Beru ¹			●	●
Volvo	C70	2007	Siemens	●			●
	S60	2005-07	Schrader	●			
	S80	2005-06	Schrader	●			
	S80	2007	Siemens	●			●
	V70	2005-07	Schrader	●			
	XC70	2005-07	Schrader	●			
	XC90	2005-07	Schrader	●			

1 - Beru Gen One 315 MHz- This sensor is on many early TPM systems from the German car companies such as Mercedes, Audi, and VW. To get a reading from a GEN 1 315 MHz sensor, you must first select position 7 on the TECH300 (scroll through by pressing the select button until LED's 3 and 4 are BOTH lit) and then let air out of the tire for 10 to 15 seconds or if the tire is flat inflate with 80 psi of force to manufacturer recommended tire PSI. This will force the sensor to transmit. Once you have let the air out of the tire, place the tool against the wheel and press test - WAIT FOR THE AUDIBLE TONE.

2 - Schrader Magnet Only - These early sensors only transmit when a ring magnet (supplied in your TECH300 kit) is placed around the stem of the sensor. Select position 11 on the TECH300 tool, place the tool against the tire and place the magnet on the stem. Press test - WAIT FOR THE AUDIBLE TONE.

3 - Pacific 125 kHz - New for MY07, this Pacific Sensor is different from its predecessor as it wakes up with a 125kHz datagram. Activate this sensor as you would any LF Activated Sensor.

4 - Pacific 309 MHz - Lexus and Toyota use this original style Pacific Sensor. The only way to wake it up is to let air out of the tire. Select position 9 on the TECH300 (scroll through by pressing the select button until LED's 2,3, and 4 are ALL lit) and perform the same procedure as NOTE 1.

5 - Siemens - Activate this sensor by letting the air out of the tire. Select position 3 and operate as per NOTE 1.

6 - Siemens - A new variation of sensor that uses a different transmit protocol. The TECH300 will wake up this sensor using position 3, but the decoding protocol is scheduled for a future software release.

7 - TRW - Special command to enable (or turn on) the accelerometer. This must be done in order for the sensor to function properly.

8 - Beru Gen One 433 MHz- This sensor is on many early TPM systems from the German car companies such as Mercedes, Audi, and VW. To get a reading from a GEN 1 433 MHz sensor, you must first select position 8 on the TECH300 (scroll through by pressing the select button until LED's 1, 3 and 4 are lit) and then let air out of the tire for 10 to 15 seconds or if the tire is flat inflate with 80 psi of force to manufacturer recommended tire PSI. This will force the sensor to transmit. Once you have let the air out of the tire, place the tool against the wheel and press test - WAIT FOR THE AUDIBLE TONE.

9 - For this particular model the sensor may be either Beru Gen 1 315 or 433 Mhz. In using the tool try position 7 with note 1. If this fails try position 8 with note 8. Last digits in OEM part number will be 275 or 275A.